

Brand	Series	Model	Size in KW	No Of Phases	Equipment Category
Fronius	Eco	Eco 25.0-3-S (AS4777-2 2020)	25	3	Grid Connect PV Inverter
		Eco 27.0-3-S (AS4777-2 2020)	27	3	Grid Connect PV Inverter
	Primo	Primo 3.0-1 (AS4777-2 2020)	3	1	Grid Connect PV Inverter
		Primo 3.5-1 (AS4777-2 2020)	3.5	1	Grid Connect PV Inverter
		Primo 3.6-1 (AS4777-2 2020)	3.68	1	Grid Connect PV Inverter
		Primo 4.0-1 (AS4777-2 2020)	4	1	Grid Connect PV Inverter
		Primo 4.6-1 (AS4777-2 2020)	4.6	1	Grid Connect PV Inverter
		Primo 5.0-1 (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		Primo 5.0-1 AUS (AS4777-2 2020)	4.6	1	Grid Connect PV Inverter
		Primo 5.0-1 SC (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		Primo 6.0-1 (AS4777-2 2020)	6	1	Grid Connect PV Inverter
		Primo 8.2-1 (AS4777-2 2020)	8.2	1	Grid Connect PV Inverter
		Primo GEN24 10.0 (AS4777-2 2020)	10	1	Multiple Mode Inverter - PV Only
		Primo GEN24 10.0 Plus (AS4777-2 2020)	10	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 3.0 (AS4777-2 2020)	3	1	Multiple Mode Inverter - PV Only
		Primo GEN24 3.0 Plus (AS4777-2 2020)	3	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 3.6 (AS4777-2 2020)	3.68	1	Multiple Mode Inverter - PV Only
		Primo GEN24 3.6 Plus (AS4777-2 2020)	3.68	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 4.0 (AS4777-2 2020)	4	1	Multiple Mode Inverter - PV Only
		Primo GEN24 4.0 Plus (AS4777-2 2020)	4	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 4.6 (AS4777-2 2020)	4.6	1	Multiple Mode Inverter - PV Only
		Primo GEN24 4.6 Plus (AS4777-2 2020)	4.6	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 5.0 (AS4777-2 2020)	5	1	Multiple Mode Inverter - PV Only
		Primo GEN24 5.0 Plus (AS4777-2 2020)	5	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 6.0 (AS4777-2 2020)	6	1	Multiple Mode Inverter - PV Only
		Primo GEN24 6.0 Plus (AS4777-2 2020)	6	1	Multiple Mode Inverter - PV and Battery
		Primo GEN24 8.0 (AS4777-2 2020)	8	1	Multiple Mode Inverter - PV Only
		Primo GEN24 8.0 Plus (AS4777-2 2020)	8	1	Multiple Mode Inverter - PV and Battery
	Symo	Symo 10.0-3-M (AS4777-2 2020)	10	3	Grid Connect PV Inverter
		Symo 12.5-3-M (AS4777-2 2020)	12.5	3	Grid Connect PV Inverter
		Symo 15.0-3-M (AS4777-2 2020)	15	3	Grid Connect PV Inverter
		Symo 17.5-3-M (AS4777-2 2020)	17.5	3	Grid Connect PV Inverter
		Symo 20.0-3-M (AS4777-2 2020)	20	3	Grid Connect PV Inverter
		Symo 3.0-3-M (AS4777-2 2020)	3	3	Grid Connect PV Inverter
		Symo 3.7-3-M (AS4777-2 2020)	3.7	3	Grid Connect PV Inverter
		Symo 4.5-3-M (AS4777-2 2020)	4.5	3	Grid Connect PV Inverter
		Symo 5.0-3-M (AS4777-2 2020)	5	3	Grid Connect PV Inverter
		Symo 6.0-3-M (AS4777-2 2020)	6	3	Grid Connect PV Inverter
		Symo 7.0-3-M (AS4777-2 2020)	7	3	Grid Connect PV Inverter
		Symo 8.2-3-M (AS4777-2 2020)	8.2	3	Grid Connect PV Inverter
		Symo GEN24 10.0 (AS4777-2 2020)	10	3	Multiple Mode Inverter - PV Only
		Symo GEN24 10.0 Plus (AS4777-2 2020)	10	3	Multiple Mode Inverter - PV and Battery
Symo GEN24 3.0 (AS4777-2 2020)		3	3	Grid Connect PV Inverter	
Symo GEN24 3.0 Plus (AS4777-2 2020)		4.5	3	Multiple Mode Inverter - PV and Battery	
Symo GEN24 4.0 (AS4777-2 2020)		4	3	Grid Connect PV Inverter	
Symo GEN24 4.0 Plus (AS4777-2 2020)		4	3	Multiple Mode Inverter - PV and Battery	
Symo GEN24 5.0 (AS4777-2 2020)		5	3	Grid Connect PV Inverter	
Symo GEN24 5.0 Plus (AS4777-2 2020)		5	3	Multiple Mode Inverter - PV and Battery	

		Symo GEN24 6.0 (AS4777-2 2020)	6	3	Multiple Mode Inverter - PV Only
		Symo GEN24 6.0 Plus (AS4777-2 2020)	6	3	Multiple Mode Inverter - PV and Battery
		Symo GEN24 8.0 (AS4777-2 2020)	8	3	Multiple Mode Inverter - PV Only
		Symo GEN24 8.0 Plus (AS4777-2 2020)	8	3	Multiple Mode Inverter - PV and Battery
GoodWe	NS	GW3000D-NS (AS4777-2 2020)	3	1	Grid Connect PV Inverter
		GW4200D-NS (AS4777-2 2020)	4.2	1	Grid Connect PV Inverter
		GW5000D-NS (AS4777-2 2020)	4.999	1	Grid Connect PV Inverter
	MS	GW5000-MS (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		GW6000-MS (AS4777-2 2020)	6	1	Grid Connect PV Inverter
		GW8500-MS (AS4777-2 2020)	8.5	1	Grid Connect PV Inverter
		GW10K-MS (AS4777-2 2020)	10	1	Grid Connect PV Inverter
	EH	GW3600-EH (AS4777-2 2020)	3.6	1	Multiple Mode Inverter - PV and Battery
		GW5000-EH (AS4777-2 2020)	5	1	Multiple Mode Inverter - PV and Battery
		GW6000-EH (AS4777-2 2020)	6	1	Multiple Mode Inverter - PV and Battery
	ET	GW5KL-ET (AS4777-2 2020)	5	3	Multiple Mode Inverter - PV and Battery
		GW6KL-ET (AS4777-2 2020)	6	3	Multiple Mode Inverter - PV and Battery
		GW8KL-ET (AS4777-2 2020)	8	3	Multiple Mode Inverter - PV and Battery
GW10KL-ET (AS4777-2 2020)		10	3	Multiple Mode Inverter - PV and Battery	
Growatt	MIN	MIN 2500TL-X (AS4777-2 2020)	2.5	1	Grid Connect PV Inverter
		MIN 3000TL-X (AS4777-2 2020)	3	1	Grid Connect PV Inverter
		MIN 3600TL-X (AS4777-2 2020)	3.6	1	Grid Connect PV Inverter
		MIN 4200TL-X (AS4777-2 2020)	4.2	1	Grid Connect PV Inverter
		MIN 4600TL-X (AS4777-2 2020)	4.6	1	Grid Connect PV Inverter
		MIN 5000TL-X (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		MIN 6000TL-X (AS4777-2 2020)	6	1	Grid Connect PV Inverter
	MOD	MOD 11KTL3-X-AU (AS4777-2 2020)	11	3	Grid Connect PV Inverter
		MOD 10KTL3-X-AU (AS4777-2 2020)	10	3	Grid Connect PV Inverter
		MOD 9000TL3-X-AU (AS4777-2 2020)	9	3	Grid Connect PV Inverter
		MOD 8000TL3-X-AU (AS4777-2 2020)	8	3	Grid Connect PV Inverter
		MOD 7000TL3-X-AU (AS4777-2 2020)	7	3	Grid Connect PV Inverter
		MOD 6000TL3-X (AS4777-2 2020)	6	3	Grid Connect PV Inverter
		MOD 5000TL3-X (AS4777-2 2020)	5	3	Grid Connect PV Inverter
		MOD 4000TL3-X (AS4777-2 2020)	4	3	Grid Connect PV Inverter
MOD 3000TL3-X (AS4777-2 2020)	3	3	Grid Connect PV Inverter		
SMA	SB	SB3.0-1AV-41 (AS4777-2 2020)	3	1	Grid Connect PV Inverter
		SB4.0-1AV-41 (AS4777-2 2020)	4	1	Grid Connect PV Inverter
		SB5.0-1AV-41 (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		SB6.0-1AV-41 (AS4777-2 2020)	6	1	Grid Connect PV Inverter
	STP	STP3.0-3AV-40 (AS4777-2 2020)	3	3	Grid Connect PV Inverter
		STP4.0-3AV-40 (AS4777-2 2020)	4	3	Grid Connect PV Inverter
		STP5.0-3AV-40 (AS4777-2 2020)	5	3	Grid Connect PV Inverter
		STP6.0-3AV-40 (AS4777-2 2020)	6	3	Grid Connect PV Inverter
		STP 50-41 (AS4777-2 2020)	50	3	Grid Connect PV Inverter
		STP8.0-3AV-40 (AS4777-2 2020)	8	3	Grid Connect PV Inverter
		STP10.0-3AV-40 (AS4777-2 2020)	10	3	Grid Connect PV Inverter
		SOFAR 3KTLM-G3 (AS4777-2 2020)	3	1	Grid Connect PV Inverter
		SOFAR 3.6KTLM-G3 (AS4777-2 2020)	3.68	1	Grid Connect PV Inverter
		SOFAR 4.6KTLM-G3 (AS4777-2 2020)	4.6	1	Grid Connect PV Inverter

Sofar	G3	SOFAR 5KTLM-G3 (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		SOFAR 6KTLM-G3 (AS4777-2 2020)	6	1	Grid Connect PV Inverter
		SOFAR 5KTLM-G3-A (AS4777-2 2020)	5	1	Grid Connect PV Inverter
		SOFAR 7KTLM-G3 (AS4777-2 2020)	7	1	Grid Connect PV Inverter
		SOFAR 8KTLM-G3 (AS4777-2 2020)	8	1	Grid Connect PV Inverter
		SOFAR 9KTLM-G3 (AS4777-2 2020)	9	1	Grid Connect PV Inverter
		SOFAR 10KTLM-G3 (AS4777-2 2020)	10	1	Grid Connect PV Inverter
		SOFAR 4KTLM-G3 (AS4777-2 2020)	4	1	Grid Connect PV Inverter
Sungrow	SH	SH5.0RT (AS4777-2 2020)	5	3	Multiple Mode Inverter - PV and Battery
		SH10RT (AS4777-2 2020)	9.999	3	Multiple Mode Inverter - PV and Battery
	SG	SG5.0RT (AS4777-2 2020)	5	3	Grid Connect PV Inverter
		SG7.0RT (AS4777-2 2020)	6.999	3	Grid Connect PV Inverter
		SG8.0RT (AS4777-2 2020)	8	3	Grid Connect PV Inverter
		SG15RT (AS4777-2 2020)	15	3	Grid Connect PV Inverter
SG20RT (AS4777-2 2020)	20	3	Grid Connect PV Inverter		